



FIG. 1




FIG. 2




FIG. 3A




FIG. 3B

A graphical user interface window titled "OPTIONS" is shown. The window contains a list of menu options, each preceded by a checkbox. The options are:

- ☐ ASSIGN MY MENU — 31
- ☐ EDIT TITLE — 32
- ☐ DELETE
- ☐ DELETE ALL
- ☐ SET WALLPAPER — 33

Below the list, there is a separate box containing the option:

- ☐ SET ICON — 34

At the bottom of the window, there is a directional pad (a square with four arrows pointing up, down, left, and right) and an "OK" button (a small square).

FIG. 3C




FIG. 4A




FIG. 4B




FIG. 4C




FIG. 4D




FIG. 5A




FIG. 5B

